. Mars Fortune .

(Manual Version : MF_US-070423)

2

MF_US-070423

Table of Contents

Interface & Button Layout	p.	04
Information	р.	05
Data Setting	р.	06
Bookkeeping	р.	09
Shift Record	р.	14
I/O Test	р.	15
History	р.	16
How to Play – Main Game	р.	17
How to Play – Free Game	р.	18
How to Play – Laser Gun	р.	19
How to Play – Jackpot	р.	20
How to Play – Double Up	р.	21
Bonus Game – Power Collection	р.	23
Bonus Game – Mineral Factory	р.	25
Bonus Game – Mineral Merchandise	р.	27
Skill Mode	р.	29
Troubleshooting	р.	31
Button Lamp List – Error Condition	р.	32
Pay Table	р.	33
Data Setting List	р.	34
Special Note	р.	36
Pin Layout	p.	37



Button Layout

Ticket Pay Info Out Out Stop 1	Auto Play D Stop 2	Select Line Double Stop 3	Take Stop 4	Play Stop 5	Start Stop
-----------------------------------	-----------------------------	--	--------------------	--------------------	-------------------

According to Pin Layout.....p. 34

4

Information

1. Turn on **Account** switch to enter the **Setup Menu** page.



- 2. Select Information and press **Start** button to enter the **Information** page.
- 3. Press **Take** button to exit the **Information** page.



DATA	SETTING	-	
DIT LIMIT		20000	
IN IN/CREDIT		25	
IN OUT LIMIT		500	
IN/CREDIT		1000	

KEY IN

CONTINUOUS

10 (250)

8 HARDEST

5 HARDEST

1000

25

50

ON ON

Data Setting

CRI

CO KE

KEY OUT TYPE TICKET OUT/CREDIT

MAX. PLAY

MIN. PLAY

AUTO PLAY

DOUBLE UP

INFO TABLE

JP MIN PLAY

MAX. TICKET PER GAME :

LEVEL OF DIFFICULTY :

[DEFAULT:PLAY+AUTO PLAY] [GAME RESET:PLAY+INFO] [UP:SELECT LINE] [DOWN:PLAY] [CHANGE:START] [EXIT:TAKE]

	INTO SCORE
PLAY SCORE	YES
BOOKKEEPING	ON
AME TYPE	NORMAL
RESET CODE TYPE	OFF
GAME COUNT	OFF
10 TIME FEATURE	OFF
CONTINUOUS SPIN	OFF
DEMO SOUND	ON
SOUND VOLUME	70
PLAY MODE	REELS
OPPER SENSOR	NORMAL HIGH

- 1. Turn on **Account** switch to enter the **Setup Menu** page.
- 2. Select **Data Setting** and press **Start** button to enter the **Data Setting** page.
- 3. Press **Play** and **Auto Play** buttons to restore the factory setting and the data will return to default.
- 4. Press Play and Info buttons to reset the bookkeeping data &

6

MF_US-070423

history , the settings won't be changed.

- 5. Press Select Line or Play button to select the item.
- 6. Press **Start** button to change the value.
- 7. Press Take button to exit the Data Setting page



- 1. Press Select Line button to select the item for changing.
- 2. Press **Start** button to enter your decision.
- 3. If you decide not to reset, it will return to **Data Setting** page ; if you decide to reset, it will return to **Demo**.

(The program will once again reconfirm reset instruction

8

Bookkeeping

во	OKKEE	CP ING
TOTAL KEY	IN :	0 (UNIT:1000)
TOTAL COIN	IN :	0 (UNIT:25)
TOTAL KEY O	UT :	0 (UNIT:1000)
TOTAL PAY O	UT :	0 (UNIT:25)
TOTAL TICKET O	UT :	0 (UNIT:1000)
KEY OUT REMAIND	ER :	0
CREDIT		0
SCORE		0
TOTAL PROF	IT :	0
PAY OUT RA	TE :	0.0 %

Bookkeeping page 1/10

- 1.
- Turn on **Account** switch to enter the **Setup Menu** page. Select **Bookkeeping** and press **Start** button to enter the 2. Bookkeeping page.
- **3.** Press **Select Line** or **Play** button to select the page. Press **Take** button to exit the **Bookkeeping** page.

BOOKKEEPING					
TOTAL	L PLAY	TIMES		0	
TOTAL	L WIN	TIMES		0	
HIT	FRE	QUENCY		0.0 %	
MAIN	GAME	IN		0	
MAIN	GAME	OUT		0	
MAIN	GAME	RATE		0.0 %	
FREE	GAME	TIMES		o	
FREE	GAME	OUT		0	

Bookkeeping page 2/10

	BOOH	KEE	PING
JP1	TIMES		0
JP2	TIMES		0
JP3	TIMES		0
JP1	OUT		0
JP2	OUT		0
JP3	OUT		0

Bookkeeping page 3/10

9

Bookkeeping page 5/10

PLAY	DOUBLE 1	JP	TIMES:	0
IN	DOUBLE I	JP	TIMES :	0
OUBL	E UP HI	r FRI	EQUENCY :	0.0
OTAL	DOUBLE	UP	IN:	o
OTAL	DOUBLE	UP	OUT :	0
TAL	DOUBLE	UP	RATE :	0.0

Bookkeeping page 4/10

PLAY	POWER	COLLECTION	TIMES:	c
PLAY	MINERAL	FACTORY	TIMES:	0
PLAY	MINERAL	MERCHANDISE	TIMES:	c
TOTAL	BONUSGA	Æ	TIMES:	c
TOTAL	POWER	COLLECT ION	OUT :	¢
TOTAL	MINERAL	FACTORY	OUT :	c
TOTAL	MINERAL	MERCHANDISE	OUT :	c
TOTAL	BONUSGAN	Æ	OUT :	c

Bookkeeping page 7/10

BOOKKEEPING				
ଲ୍ଲାଲ୍ଲାଲ୍ଲ ଲ _େ	🤹 🎕 🎕 🎕 x o			
2 de de x o	a 🖞 🖗 🖗 xo			
₽₽₽₽×□	262626×0			
🏟 🏟 🏟 🗢 x o	果 果 果 果 ×o			
A A A A X 0	al al al al ×o			
(骨)(骨)(骨)(骨)×0				
瀛瀛瀛瀛xo —				

Bookkeeping page 6/10

BOOKKEE	PING
'꽃''''''''''' '꽃' X D	🥙 🥙 🦓 x o
🔂 🧔 🖉 x o	a 🕺 🚽 x o
💂 💂 💂 x o	Za Za × o
🗇 🍚 🗇 x o	💂 💂 🗶 x o
A A A X O	a a a x o
(音)(音)(音)×0	
派派派xo	
heltelter	

Shift Record

BOO	KKEEPING
윷 등 등 등 등 등 ×	- 🦓 🆓 🆓 🆓 🆓 xo
e e e e e e x o	a a a a a a a a
₽ ₽₽₽₽₽	
\$ \$ \$ \$ \$ \$ \$ \$ \$ \$	奥 奥 奥 奥 奥 × •
<u>AAAAA</u> xo	a) a) a) a) a) × ·
働(骨)(骨)(骨)×o	
XXXXXXXX -	

Bookkeeping page 8/10



-	SHIFT RECO	1D			
	c	IRREN	T SF	HET	
	ĸ	EY IN	1		0
	c	OIN I	N		0
	к	EY OU	r		0
	F	AY OU	T		0
	т	ICKET	our	•	0
LSHI					

Bookkeeping page 10/10

- 1.
- 2.
- Press **Start** and **Auto Play** buttons to shift. Press **Select Line** or **Play** button to select the page. Press **Take** button to exit the **Bookkeeping** page. 3.

I/O Test

		170 11	201	
START/STOP		OFF	COIN IN	OF
PLAY/STOP5		OFF	KEY IN	OF
SEL./DOUBLE/STOPS	F :	OFF	KEY OUT	OF
AUTO PLAY/STOP2		OFF	HOPPER	OF
INFO/STOP1/SKILL		OFF	ACCOUNT	OF
PAY OUT		OFF	TEST	OF
TICKET OUT		OFF	DOOR	OF
TICKET SWITCH		OFF	TAKE/STOP4	OF

- 1. Turn on **Account** switch to enter the **Setup Menu** page.
- 2. Select I/O Test and press Start button to enter the I/O Test page.
- 3. Press **Take** button 2 seconds to exit the **I/O Test** page.



- 1. Turn on **Account** switch to enter the **Setup Menu** page.
- 2. Select **History** and press **Start** button to enter the **History** page.
- 3. Press Select Line or Play button to select the page.
- 4. Press **Take** button to exit the **History** page.

How to play

A. Main Game



15 reels-25 liner style



Pay Chart

B. Free Game



The game will randomly give away 6~10 rounds of free games.



18

C. Laser Gun



Occasionally, the "Laser Gun" will shift symbols to increase the winning opportunity. EX :



- D. Jackpot
 - 1. JP1: (Random JP)



When player's play as JP MIN. Play and hit more than 3 **Spaceman** symbols, they will be awarded the JP1 Bonus.JP1 is a random bonus ranging from **550~650** times of Total Play.

2. JP2:(Random JP)



When player's play as JP MIN. Play and hit more than 3 **Space Shuttle** symbols, they will be awarded the JP2 Bonus. JP2 is a random bonus ranging from **350~450** times of Total Play.

3. JP3: (Random JP)



When player's play as JP MIN. Play and hit more than 3 **Martian** symbols, they will be awarded the JP3 Bonus. JP3 is a random bonus ranging from **150~250** times of Total Play.

Symbol Of a kind			
3	1/4 JP1	1/4 JP2	1/4 JP3
4	1/2 JP1	1/2 JP2	1/2 JP3
5	JP1	JP2	JP3

E. Double Up

1. After winning in the main game, players may press DOUBLE button to play the Double Up game.



2. The Double Up game can be played for maximum of 5 times.



3. Enemy UFO splits into two, one real and one fake. Select the real UFO and press DOUBLE button to attack.

4. When you hit the fake UFO, the real one will flee away, and you lose the Double Up game.



5. If hit the real UFO will cause it to damage, and your winning will be doubled. Continuously hit the UFO 5 times will cause it to crash, and you will get another extra bonus.



6. Before the beginning of each round, player may press TAKE button to claim current winning and exit the Double Up game.

BONUS GAME

A. Power Collection

1. Hit 3 Mars Medal symbols in the main game will trigger the Power Collection bonus game.



2. The time limit of Power Collection bonus game is 30 seconds. The game is over when the time is up, and then will count game score.



3. There are 6 energy towers in the power plant, light up like roulette, press STOP button to start collect energy.

4. If the player stop at a tower hasn't been chosen before, the plant will collect energy again with all chosen towers.



5. If the player stop at a tower has been chosen before will cause the tower to overact and explode. The game will be over.



6. Winning = Total Play × Game Score.

B. Mineral Factory

1. Hit 4 Mars Medal symbols in the main game will trigger the Mineral Factory bonus game.



2. The time limit of Mineral Factory bonus game is 30 seconds. The game is over when the time is up, and then will count game score.



3. The product line will send out 3 minerals each round, select one and press START button to cut.

4. If a gem inside, the gem will convert to odds. If an energy ore inside, the laser cutter's energy will be refilled.



5. If the player can't get an energy ore in consecutive 3 rounds, or if a booby trap inside, the game will be over.



6. Winning = Total Play × Game Score.

C. Mineral Merchandise

1. Hit 5 Mars Medal symbols in the main game will trigger the Mineral Merchandise bonus game.



2. The time limit of Mineral Merchandise bonus game is 30 seconds. The game is over when the time is up, and then will count game score.



- **3.** The credit brought in to buy the mineral equal to the player's total play. In the beginning the player can only offer some minerals, press START button to buy one.
- 4. The chosen mineral will be sent to cut and the gem inside $_{\rm MF_US-070423}$

will convert to credit and return to account.



5. Game will be over if the player can't offer any mineral or there is no mineral on the shelf.



6. Winning = Total Play +Profit. And the player may press TAKE button to claim current winning at anytime.

SKILL MODE

- A. Enter Data Setting page and turn on $"SKILL MODE_{J}$.
- **B.** A frame appears on a reel after press START button to stop the reels in a main game.



C. Press **Info** button to move the position of frame and determine which reel will be reserved. Only one reel will be reserved.



D. Press START button again to respin the other four reels.



E. Game result appears after the reels stop.



30

Troubleshooting

If the program detects an error, the corresponding message will be shown on the screen, please find the troubleshooting method as following.

Error Message	Procedure
Compact Flash	The version of program is incorrect
Error	Please talk to your provider.
Coin Iam	1. Repair the coin selector and coin entrance.
Colli Jain	Enter and exit the "Data Setting" page.
Credit Over	Press Key Out, Payout, or Ticket Out.
Data Error	Enter the "Data Setting" page and reset the
	bookkeeping data.
	1. Repair the coin out transporter or hopper.
	2. Enter the "Data Setting" page and change the
HOPPER ERROR	setting of HOPPER SENSOR to NORMAL
	HIGH or NORMAL LOW.
	3. Exit the "Data Setting" page.
Hopper Empty	Refill the coin hopper.
Transfer Error	Restart the machine.
Hardwaro Error	1. Restart the machine.
I Ialuwale Litu	If no effect, please contact provider.
Up Board Error	Please contact the provider.
	1. When the opening animation starts, press
No Imogo	Account button to enter the "Setup Menu"
ino image	Page.
	2. Select the item for more information.

Button Lamp List – Error Condition

Error Message	Procedure
Before Start The	The Tower Lamp and Button Lamps flash one
After Start The Game	The Tower Lamp flash Alternately.
RAM ERROR	The Error Tower Lamp and 2 Button Lamps flash Alternately.
EEPROM ERROR	The Error Tower Lamp and 3 Button Lamps flash Alternately.
ROM ERROR	The Error Tower Lamp and 4 Button Lamps flash Alternately.
CRASH	The Error Tower Lamp and 5 Button Lamps flash Alternately.

32

Pay Table



Data Setting List

	Entry	Value
1	Credit Limit	1000, 3000, 5000, 10000, <u>20000</u> , 50000, 100000,
		990000
2	Coin	1, 2, 3, 4, 5, 10, 15, 20, <u>25</u> , 30, 40, 50, 60, 75, 80,
	In/Credit	100, 200, 250, 400, 500, 1000
3	Coin Out	100 200 300 500 1000 2000 3000 5000 10000
	Limit	100, 200, 300, <u>300</u> , 1000, 2000, 3000, 3000, 10000
4	Key In/Credit	1, 2, 3, 4, 5, 10, 15, 20, 25, 30, 40, 50, 60, 75, 80,
		100, 200, 250, 400, 500, <u>1000</u>
5	Key Out Type	<u>Key In</u> , Coin In, Clear All
6	Ticket	1, 2, 3, 4, 5, 10, 15, 20, 25, 30, 40, 50, 60, 75, 80,
	Out/Credit	100, 200, 250, 400, 500, <u>1000</u>
7	Max. Ticket	Continuous $1, 2, 3, 4, 5, 8, 10$
	Per Game	<u>Continuous</u> , 1, 2, 5, 4, 5, 8, 10
8	Max. Play	25, 50, 75, 100, 125, 150, 175, 200, 225, <u>250</u> , 275,
		300, 375, 500
9	Min. Play	1, 3,5, 7, 9, 10, 15, 20, <u>25</u> , 50, 75, 100, 150, 200,
		250, 300, 500
10	JP Min. Play	9, 25 , 50, 75, 100, 150, 200, 250, 300, 500
11	Auto Play	On, Off
12	Info Table	<u>On</u> , Off
13	Level Of	1 (EASIEST) 2 3 4 5 6 7 8 (HADDEST)
	Difficulty	1(EASILS 1), 2, 3, 4, 5, 0, 7, $0(HARDES 1)$
14	Double Up	Off, 1 (EASIEST), <u>2</u> , 3, 4, 5 (HARDES)
15	Winning Type	Into Score, Into Credit
16	Play Score	No, <u>YES</u>
17	Bookkeeping	<u>On</u> , Off
18	Game Type	Normal, Skill
19	Reset Code	Table1, Table2, Table3, Table4, Table5, Table6, Table7,
	Type	Off
20	Game Count	On, <u>Off</u>
21	10 Time	On. Off
22	Feature Continuour	
22	Spin	On, <u>Off</u>

23	Demo Sound	<u>On</u> , Off
24	Sound Volume	0, 5, 10, 15, 20 , 25, 30, 35, 40, 45, <u>50</u> , 55, 60, 65, 70, 75, 80, 85, 90, 95, 100
25	Play Mode	Reels, Flying
26	Hopper Sensor	<u>Normal High</u> , Normal Low

Special Note

Reset Code Type(Data Setting 19th item):"PASSAGE" page will show on the screen when the 19th item was be changed.

SETUP PASSWORD	
PASSWORD : OFF	
NEXT PAGE : DOUBLE [PREV PAGE : BET] [EXIT : TAKE]	

- 1. Press **Select Line** button to select the unit for changing.
- 2. Press **Play** button to change the value.
- 3. Press **Start** button to input the password. If the password is correct, then will enter **Data Setting** page; or will show PASSWORD ERROR.
- 4. Press **Take** button to exit the **Input Password** page, then will return to **Setup Menu** page.

You can see one unit of password while you're inputting , after you change ,the former unit will show as $*_{\circ}$

Table	1	2	3	4	5	6	7
Password	658224	441578	956334	758452	458912	548814	198427

Pin Layout							
CONNECTOR (36PIN)							
PARTS SIDE		SOLDER SIDE					
	1						
	2						
Speaker R +	3	Speaker R -					
Speaker L +	4	Speaker L -					
	5						
THE OFFICE	6						
Licket Out Button	7						
licket Notch(Dispenser)	8						
Start / Stop Button	9						
Info/Stop1Button	10						
Play/Stop5 Button	11						
Take/Stop4 Button	12						
Select Line							
Double/ Stop 3	13						
Button							
START SIGNAL	14						
	15						
Auto/Stop2 Button	16						
	17						
Coin In Switch	18	Key In Switch					
Door Switch	19						
Account 1	20	Account 2					
Pay Out Button	21	Key Out Switch					
	22	Hopper Switch					
Coin In Meter	23						
Key In Meter	24	Hopper SSR					
	25						
5 6	26						
Pay Out Meter	27						
Key Out Meter	28	T + 4 0 4 00D					
Start / Stop Lamp	29	Licket Out SSR					
Info/Stop1 Lamp	30	Error Lamp					
Play/Stop5 Lamp	31	Win Lamp					
Take/Stop4 Lamp	32						
Select Line/	~~						
Double/	33						
Stop3 Lamp	04						
Auto/Stop2 Lamp	34						
	35						
GND	36	GND					

CONNECTOR (10PIN)

PARTS SIDE		SOLDER SIDE
GND	1	GND
GND	2	GND
(*1) +5V	3	+5V
+5V	4	+5V
(*1) +12V	5	+12V
+12V	6	+12V
Ticket Dispenser Enable	7	
(*2) Hopper SSR	8	
GND	9	GND
GND	10	GND

(*1) DC +5V 2A and DC +12V (*2) This pip is connected with

(*2) This pin is connected with the solder side 24th of connector 36 pin.